




CETUS

CPU Holder

Models:

CCH-SIL


CCH-BLK





CETUS CPU Holder Installation Instructions:

Tools Required: Phillips Head Screwdriver

1. Attach Foam Pads (A) in location as shown.
2. Determine desired position based on the size of the CPU to be mounted and mark underside of desk.
3. Pre-drill mounting holes using a small diameter bit no larger than the shank diameter of the self-tapping wood screws (B).
NOTE: Be careful not to drill through the top of the desk.
4. Install upper portion of CPU Holder using the 6 wood screws (B).
5. Insert the lower portion of the CPU Holder into the upper guides and position it at the height necessary for the CPU being mounted. Be sure to fully engage the four hooks at the top with the appropriate slots in the back of the upper portion.
6. Secure the lower portion in place using the 2 machine screws (C).
7. Place CPU into holder and insert the spring-loaded panel, pressing it as firmly as possible into place against the CPU. The spring will lock it into position.

A)  X 12

B)  X 6

C)  X 2